



Card #5: Use Yellow Paper
Card #5: 使用黃色紙張

Cordless Scanner Memory Mode

Enable Memory Mode

Disable Memory Mode*

Send Data ①

⏴

Clear Data & Confirm ②

☑

P/N S1XXXCBS11000 1a

Cordless Scanner BT Authentication

Enable Authentication ①

Use Preset PIN <0000>*

Disable Authentication*

Use Random PIN

⏴

PIN Code Input ②

Preset PIN: Before pairing, scan barcodes at back.
Random PIN: While pairing, scan barcodes at back to input the same code displayed on the target device.

P/N S1XXXCBS21009 2a

Cordless Scanner HID Interface

Reset BT HID connection

BT HID* ①

PCAT(US)*

CipherLab dongle: USB HID* ①

PCAT(US)*

USB cable: HID ①

Memory Mode, 1661 only
PCAT(US)*

⏴

Select keyboard type ②

Scan barcodes at back.

P/N S1XXXCBS31008 3a

Cordless Scanner Virtual COM Interface

BT SPP, Slave

BT SPP, Master

CipherLab dongle: USB VCOM

USB cable: VCOM*

Memory Mode, 1661 only

P/N S1XXXCBS41007 4a

Cordless Scanner Initial Setup for Mobile Phone

iPhone, iPad HID

Random PIN: While pairing, scan barcodes at back.
HID: Transmit by Character
Enable keypad on mobile

BlackBerry, Android, Windows Mobile SPP

Preset PIN <0000>
SPP Slave Mode

Windows Mobile Preset PIN, HID

Preset PIN <0000>
HID: Transmit by Batch

Windows Mobile Random PIN, HID

Random PIN: While pairing, scan barcodes at back.
HID: Transmit by Batch

P/N S1XXXCBS51006 5a

Cordless Scanner Memory Mode

⏴

☑

P/N S1XXXCBS11000 1b

Cordless Scanner PIN Code Input

Start

⏴

0

1

2

3

4

5

6

7

8

9

End

☑

P/N S1XXXCBS21009 2b

Cordless Scanner Keyboard Type

⏴

☑

64 : PCAT(US) 69 : PCAT(Norwegian)
65 : PCAT(French) 70 : PCAT(UK)
66 : PCAT(German) 71 : PCAT(Belgium)
67 : PCAT(Italy) 72 : PCAT(Spanish)
68 : PCAT(Swedish) 73 : PCAT(Portuguese)
74 : PSS5 A01-2 (Japanese)
76 : PCAT(Turkish)

0

1

2

3

4

5

6

7

8

9

End

P/N S1XXXCBS31008 3b

Cordless Scanner Restore Defaults

Restore System Defaults

Restore User Defaults

Save as User Defaults

P/N S1XXXCBS41007 4b

Cordless Scanner PIN Code Input

Start

⏴

0

1

2

3

4

5

6

7

8

9

End

☑

P/N S1XXXCBS51006 5b

Cordless Scanner Hands-free Operation

Enable Auto-Sense

Hands-free use with BT Base, 1560/1564 only

Disable Auto-Sense*

1560/1564 only

Enable High Sensitivity

Auto-Sense Mode, 1560 only

Disable High Sensitivity*

1560 only

P/N S1XXXCBS61005 **6a**

Cordless Scanner BT Base Interface

Keyboard Wedge 1

BT Base only PCAT(US)*

2

Select keyboard type

Scan barcodes at back.

RS-232

P/N S1XXXCBS71004 **7a**

Cordless Scanner Hands-free Operation

Laser Mode*

Handheld use

Continuous Mode

Hands-free use with BT Base

Presentation Mode

Hands-free use with BT Base, 1564 only

P/N S1XXXCBS61005 **6b**

Cordless Scanner Keyboard Type

64 : PCAT(US)
65 : PCAT(French)
66 : PCAT(German)
67 : PCAT(Italy)
68 : PCAT(Swedish)

69 : PCAT(Norwegian)
70 : PCAT(UK)
71 : PCAT(Belgium)
72 : PCAT(Spanish)
73 : PCAT(Portuguese)
74 : PSS5 A01-2 (Japanese)
76 : PCAT(Turkish)

0

1

2

3

4

5

6

7

8

9

End

P/N S1XXXCBS71004 **7b**